

Packaging and Shipping

Product Number	Package Info
TDS55TL-06	Contents: 55" Display Package Dimensions: 54.25L (137 cm) x 10"W (25cm) x 34H (87cm) Shipping: Package delivery service

Contents

Boxes	Qty.	Description
Monitor	1	55" Display
	1	Power Cable
	1	Remote
Wall Mount	1	Wall Mount Instruction Sheet
	1	VESA Full-Motion Mount
	1	Hardware Kit
Components	3	Velcro Pair
	1	USB Mouse
	1	HDMI Cord (1')
	1	Extension Cord (10')
	1	3-Outlet Adapter
	1	Spectrio Media Player
	2	13" Cable Ties
4	6" Cable Ties	


Installation Requirements

Type	Description
Power	One (1) 115VAC 60Hz unswitched (always active) power outlet
Internet	Options: <ul style="list-style-type: none"> Wired Ethernet (10/100/1000BASE-T) 802.11 b/g/n wireless access point (VSN-provided) 802.11 b/g/n wireless access point (customer-provided) <ul style="list-style-type: none"> WPA2-PSK [AES] WPA2-PSK [TKIP]
Tools	Phillips-Head Screwdriver

Installation Guide


BEFORE INSTALLATION, CAREFULLY REMOVE CONTENTS FROM PACKAGING AND CONFIRM THAT ALL ITEMS ARE INCLUDED.

1. Remove the wall mount from its box and follow the instructions from the StarTech Flat-Screen TV Wall Mount Articulating guide provided.




Note: Please refer to the manufacturer's instructions for attaching the wall mount arm to the wall.

2. You will be using the Hardware from Slots M-B, M-F, W-A, W-B & W-C for this build.



3. Once the Mount is attached to the back of the TV next you will need to attach the Spectrio Media Player to the back of the display with the provided velcro (Power Button at top).

4. Connect the HDMI cable to the media player using the HDMI port next to the Power Supply Port. Then connect the HDMI to HDMI 2 slot on display.



5. Attach the power supplies for the display and media player to the included outlet adapter, and use the Velcro to tape the power brick (I) along with any excess power cord to the back of the Top of TV.



6. Next you will need to plug in the 10ft extension cord to the bottom of the outlet adapter (see picture above).

7. Follow the instructions displayed on the screen start up application to connect to your internet to pair your device and begin downloading your content.

8. If you've not yet selected content for your device, use your web browser to navigate to app.vs-networks.com, and sign into your Command account.

If you continue to have any problems, please contact Spectrio Support.

Safety Information



WARNING: Use of controls, adjustments, procedures, connections, or signal types other than those specified in your documentation may result in exposure to shock, electrical hazards, and/or mechanical hazards.

Spectrio products are not designed for use in hazardous environments.

Place equipment on a hard, level surface.

- Do not stack the equipment, place in an enclosed space, or otherwise install where it is subject to heated air. The equipment should have at least 4 inches (10.2 cm) of clearance on all vented sides to permit the airflow required for proper ventilation. Restricting airflow can damage the equipment or cause overheating.



WARNING: Do not operate the equipment with any cover(s) removed (including covers, bezels, panel inserts, and so on).

- Do not use your equipment in a wet environment. Protect equipment from liquid intrusion.
- Do not use damaged equipment, including exposed, frayed, or damaged power cords.
- Do not push any objects into the air vents or openings of your equipment. Doing so can cause fire or electric shock by shorting out interior components.
- Do not attempt to service the equipment yourself.

Description

The Spectrio Media Player is a compact and low power-consumption media player that displays high-quality, custom digital content and features automatic software updates and complete control via the Internet.

Features

Supported Content	<ul style="list-style-type: none"> Video formats <ul style="list-style-type: none"> 3G2, 3PG, ASF, AVI, M2TS, M4V, MKV, MOV, MP4, MPEG, MTS, MXF, Ogg, OGV, TS, WebM, WMV Image formats <ul style="list-style-type: none"> JPEG, PNG Microsoft PowerPoint® <ul style="list-style-type: none"> PPT PPTX
Display Resolutions	<ul style="list-style-type: none"> 1920 x 1080 (1080p) 1280 x 720 (720p)
Additional Features	<ul style="list-style-type: none"> Cloud-hosted content management system Automatic software updates


Specifications

Dimensions	38.5"L (98 cm) x 22"W (56 cm) x 6"D (15cm)
Weight	25 lbs
Power Consumption	12W (Max) 4W (Nominal) 4W (Sleep)
AC Input	100-240V AC 50 / 60Hz
Operating Temperature	40°F - 105°F
Network Connectivity	802.11 b/g/n WiFi WPA2-PSK [AES] WPA2-PSK [TKIP] Wired Ethernet (10/100/1000BASE-T)
Computer	1.8 GHz Intel Celeron N3350 Processor 4GB DDR4 RAM, 64 GB SSD Intel HD graphics

Usage Guide

Diagnostics Screen

Imagine the Tic-Tac-Toe number sequence on your screen (left picture below) and touch the screen (if you have a touchscreen setup) or use the USB mouse provided to you and click the number sequence 7002 to access the diagnostic screen (right picture below).



Restart and Shutdown

During Maintenance and troubleshooting, it may be necessary to shutdown or restart the media player. To shutdown or restart the device attach a mouse to the media player to navigate the diagnostic screen. Select the desired action from the menu options on the screen. Enter 8-9-2 on the numeric keypad and select Enter.

Note: The Passcode 8-9-2 is the default passcode for any action that must be unlocked on the diagnostic screen.

Web-Based Management Interface

The media player is fully managed via a web interface which can be accessed at app.vs-networks.com/. Using the web interface, volume controls and hours of operation can be viewed and set. User accounts are provided by the Spectrio sales team. In some cases, you may need to use a single sign-on authentication service hosted by your employer, rather than a Spectrio-provided account.

Care and Maintenance

Periodic dusting and cleaning of the media player and its display system is highly recommended. To clean, please use a dry microfiber cloth to remove any dust. The cloth can be damp, but not saturated with fluid.



WARNING: Never use alcohol or strong solvents as these will damage the media player. Do not spray liquid directly on the media player as this may cause it to seep inside and cause permanent damage!